



A2

### МОДУЛЬ ТЮНЕРА PWB 1144TU R030




A4

### Модуль фотоприемника и индикации PWB 1143IR



A5

### Модуль управления PWB 1142KEY



A6

### ПАНЕЛЬ ЖИДКОКРИСТАЛЛИЧЕСКАЯ 32"

CN1		
NC	1	1
NC	2	2
NC	3	3
GND	4	4
Rx IN0-	5	5
Rx IN0+	6	6
GND	7	7
Rx IN1-	8	8
Rx IN1+	9	9
GND	10	10
Rx IN2-	11	11
Rx IN2+	12	12
GND	13	13
Rx CLKIN-	14	14
Rx CLKIN+	15	15
GND	16	16
Rx IN3-	17	17
Rx IN3+	18	18
GND	19	19
NC	20	20
DMS	21	21
OD SEL	22	22
GND	23	23
GND	24	24
GND	25	25
VCC	26	26
VCC	27	27
VCC	28	28
VCC	29	29
VCC	30	30

CLAA320WF01SC

A6.1

### Инвертор

CN1		
GND	1	1
VBL(+24V)	2	2
VBL(+24V)	3	3
VBL(+24V)	4	4
VBL(+24V)	5	5
GND	6	6
GND	7	7
GND	8	8
GND	9	9
GND	10	10
NC	11	11
B/L ON/OFF	12	12
PDIM	13	13
NC	14	14

### Входная часть приемника DVB-T (не задействована)

